

Roof-To-Wall Transition - Parapet Wall Face - S8.1

Sheathing Wall Construction with gypsum, plywood or OSB sheathing.

Consolidate and seal any raw, cut gypsum board edges by brushing or spraying on a thin uniform coat of **GypPrime**.

Along the top edge of the non-vented parapet, apply a bead of **FastFlash** or **Joint & Seam Filler** to the seams between the back of the sheathing and the structural member, and 1 inch over the vertical face on both sides of the parapet. Spread the wet product to create a seamless transition. Allow to skin over.

Apply a thick bead of **FastFlash** or **Joint & Seam Filler** down the center of the structural member. Wet-set the wood blocking. Mechanically fasten the wood blocking. Spot the head of all fasteners that penetrate the wood blocking. Allow to skin over.

Apply a thick bead of **FastFlash** or **Joint & Seam Filler** to the joint between the wood blocking and the top of the wall. Use a dry trowel or spatula to tool and seal the joint. Create a profile that directs bulk water away from the joint. Allow to skin over.

