

R-Guard®

AIR & WATER BARRIERS

Rough Opening Using One Product - S4.1A

Sheathing Wall Construction with gypsum, plywood or OSB sheathing.

Apply a thick bead of **FastFlash** to all inside corners, joints and seams, and framing surfaces within the rough opening at 12-15 mils.

Apply a thick bead of **FastFlash** over the framing inside the rough opening and the structural wall surrounding the rough opening. Use a dry joint knife, trowel or chipper brush to spread the wet product to create a seamless flashing membrane which protects the rough opening and extends 4-6 inches over the face of the structural wall. When using a flanged window, extend **FastFlash** 2 inches beyond the edge of the window flange. Apply additional

FastFlash as needed to create an opaque, monolithic flashing membrane free of voids or pinholes.

Apply the selected R-Guard air and water-resistant barrier over the prepared sheathing. Apply sufficient product to cover the entire face of the structural wall.

When stud framing is used in lieu of track, cover knockout with breakmetal and seal edges with **FastFlash** (see insert below).

